


USER MANUAL



TRUE HEPA AIR PURIFIER

READ AND SAVE THESE INSTRUCTIONS

**LIFETIME WARRANTY IF REPLACES THE FILTER ON TIME
YOUR SATISFACTION IS OUR TOP CONCERN**

Content

Safety Information	1
Package Contents	2
Specification & Unique Features	3
Know Your Air Purifier.....	6
How To Use	8
How To Replace Filter	10
How To Use The Aroma Box.....	12
Care & Maintenance	13
Disposal and Recycling	16
Tips to Buy Air Purifier	16
Trouble Shooting	17

SAFETY INFORMATION

To reduce the risk of fire, electric shock, or other injury, follow all instructions and safety guidelines.

GENERAL SAFETY

- Use the air purifier only as described in this manual.
- Always place the unit on a firm, level surface.
- **Before first use, remove all plastic packaging from the filter.** Operation without removing the wrap will impair airflow, cause overheating, and create a fire hazard.



**IF THE POWER CORD OR UNIT DOES NOT WORK,
CONTACT OUR CUSTOMER SERVICE**

- Do not use your air purifier outdoors.
- Keep your air purifier away from water, and wet or damp areas. Never place in water or liquid.
- Do not use in excessively humid areas.
- Keep your air purifier away from heat sources.
- Do not use where combustible gases, vapors, metallic dust, aerosol (spray) products, or fumes from industrial oil are present.
- Keep 5 ft / 1.5 m away from where oxygen is being administered.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not place anything into any opening on the air purifier.
- Do not sit or place heavy objects on the air purifier.
- Keep the inside of the air purifier dry. To prevent moisture buildup, avoid placing in rooms with major temperature changes or underneath air conditioners.
- Always unplug your air purifier before servicing (such as changing the filter).

POWER & CORD

- Keep the air purifier near the outlet it is plugged into.
- Never place the cord near any heat source.
- Do not cover the cord with a rug, carpet, or other covering. Do not place the cord under furniture or appliances.
- Keep the cord out of areas where people walk often. Place the cord where it will not be tripped over.

- Check your air purifier cord and plug connections. Faulty wall outlet connections or loose plugs can cause the outlet or plug to overheat. Be sure the plug fits tightly in the outlet.

WARNING

- If the power adapter is damaged, please contact our customer service directly to replace with new replacement.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Cleaning and user maintenance shall not be made by children without supervision.
- If the product needs to be shut down during use, please shut down normally and then unplug the power supply. Abnormal power failure may cause product failure!
- Children should be supervised to ensure that children do not play with electrical appliances.
- To reduce the risk of fire, electric shock or injury to persons, do not use replacement parts that have not been recommended by the manufacturer (e.g. parts made at home using a 3d printer).

SAVE THESE IMPORTANT INSTRUCTIONS FOR EASY REFERENCE.

PACKAGE CONTENTS

- 1 x Air Purifier
- 1 x H14 True HEPA Filter (Pre-Installed)
- 1 x Power Adapter
- 1 x User Manual

NOTE: Before use, please remove the protective tape from the machine, open the air purifier panel, remove the filter inside the machine, and remove the packaging of the protective filter. Then correctly install the filter and cover the panel.

SPECIFICATION & UNIQUE FEATURES

Power Supply	100-240V 50/60hz	Rated Power	36W
Operating Conditions	Temperature: 14°F– 104°F /- 10°C–40°C Humidity: < 85% RH	Noise Level	22–45dB

Washable Pre-Filter




- **Washable Pre-Filter**

Captures large particles such as dust, lint, fibers, hair, and pet fur. Extend the life of the True HEPA Filter by protecting it.

- **Cleaning the Pre-Filter**

The Washable Pre-Filter should be cleaned every 2-4 weeks to increase efficiency and extend the life of your filter. Clean the pre-filter using a soft brush or vacuum hose to remove hair, dust, and large particles. Optionally, you can wash the pre-filter with water and a mild detergent to remove dirt and dust.

GENUINE TRUE HEPA H14 FILTRATION SYSTEM



- **TRUE HEPA H14 FILTRATION**

Removes up to 99.997% of airborne particles as small as 0.1 microns such as pet dander hair, odor, smoke and large dust from the air, more powerful than a HEPA H13 grade filter.

- **High-Efficiency Activated Carbon Filter**

Physically adsorbs smoke, odors, and fumes, especially effective for cooking smells and pet odors in a multi-pet household.

- **PRE-FILTER**

Captures large particles such as dust, lint, fibers, hair, and pet fur. Maximizes the life of the True HEPA Filter by protecting it.

- **PROTECTIVE NET FILTER**

Filter	When to Clean	How to Clean	When to Replace
Washable Pre-Filter	Every 2-4 weeks	Use a soft cloth or vacuum hose	Does not need to be replace
		Wash with water and mild detergent	
True HEPA /Activated Carbon Filter	Do not clean		3-4 months



Air Quality Indicator Chart & DIGITAL DISPLAY

This indicator uses an automatic sensor to display the air quality. This sensor uses an infrared light to detect airborne particles.

Indicator Color	Blue	Green	Yellow	Red
Air Quality	Very Good	Good	Moderate	Polluted
PM2.5 Level	0-35	36-75	76- 115	> 116



4 SPEEDS

1.Low; 2.Medium; 3.High; 4.Pet Mode



Auto Mode

Auto Mode adjusts the fan speed automatically based on air quality. For example, if the air quality is polluted, the PM2.5 indicator will be red, and the fan will be set to turbo speed.



Quiet Sleep Mode

All indicators will automatically turn off in sleep mode, only sleep mode indicator on.



Timer

You can set a timer 2,4,6, 8 hours.



Replace Filter Indicator

HEPA light illuminates when it is time to replace the filter.



Child & Pets Lock


Prevents accidental changes to settings. Great for nurseries, living rooms, or pet-friendly homes.




Aroma Diffuser

You can choose different essential oils based on your personal preferences to create a customized ambiance at home.


KNOW YOUR AIR PURIFIER



- A: Control Panel
- B: Air Inlet
- C: Body Shell
- D: Air Outlet
- E: Air Quality Sensor
- F: Power Adapter Interface
- G: H14 HEPA Filter
- H: Washable Filter
- I: Air filter cover



CONTROL PANEL



- A: On/Off WiFi Button

C: Fan Speed Button

E: Timer Button


G: Child Lock Button
- B: Sleep Mode Button

D: Pet Mode Button

F: Filter Reset Button

H: Air Quality indicator

LED Display



Sign	A	1	2	3	Pet
Fan Speed	Auto Mode	Low	Medium	High	Pet Mode

Note: all indicators on Led Display are not buttons, please use buttons on control panel.

HOW TO USE

BEFORE TURNING THE UNIT ON

- 1. Take the air purifier out of the box and remove the clear protective plastic bag.
- 2. Open the purifier cover from the notches on both sides to take filter out.
- 3. Install the two filter (remove the protective plastic bag) and reset the cover
- Place the air purifier on a firm, leveled surface.
- Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect the appliance.
- Please insert the plug into the power socket firmly. After switching the power on, the indicator light will flash.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlets closer than 20cm.
- For best results, or to address a specific air quality issue such as smoke, run the air purifier at high speed for 15-20 minutes before using a lower speed or Auto Mode, and keep windows and doors closed while the air purifier is on.

TURN ON / OFF

- To turn the air purifier on, press the power  button.
- Press power button again to turn off the air purifier.
- The air purifier will take about 15-20 seconds to detect the air quality each time it is turned on. During this time, the air quality indicator color will switch automatically from red, blue, green, yellow. After 15-20 seconds, the air quality indicator color will change based on the detected air quality. And the air pollution value is displayed in the front panel display.

Note: air purifier is automatically in auto mode when turn on every time.

Switch Fan Speed

- This air purifier has 4 fan speed settings: low, medium, high and Pet Mode. The higher the fan speed setting, the faster the air will be purified. To selector change fan speed, press the fan speed button  until the desired setting is reached.
- Press the pet mode  to increases fan speed to quickly capture pet dander, hair, and odors.
- The speed indicator will change to show your current selection. Please check “LED Display” content for reference.

Auto Mode

- When at turbo speed, press fan speed button  again to switch to auto mode. The auto mode indicator **A** will light on LED Display. Then air purifier speed will automatically adjust based on air quality. If air quality is moderate, the PM2.5 indicator will be yellow, and air purifier will run at high speed.
- Press  button again change to low speed, and auto mode turned off.
Note: air purifier is automatically in auto mode when turn on every time, not the speed you used last time.

Timer

- Press the timer button  until the desired timer setting is lit on the display. The timer button will cycle through the following settings: 2-4-6-8 hours and off. Once you choose a time, the timer will flash 10 times and start counting down. The air purifier will automatically power off once the timer is finished. If the timer indicator is off, the timer function is not active.
- To cancel the timer at any time, press the timer button and hold it for 2 seconds. If canceled successfully, the timer indicator will be off on the display.

Note: the air purifier will run continuously when the timer function is off.

SLEEP MODE

- Press button  to switch to sleep mode. All indicators will turn off automatically except the sleep mode indicator with only little light.
- Press sleep mode button again to turn off sleep mode, air purifier will run at low fan speed.

Note: Sleep mode indicator could not turn off.

If you press  on/off button at sleep mode, the air purifier will be turn off immediately.

Child & Pets Lock

- Press the child lock & Pets Lock button  and hold it for 2 seconds then all functional buttons will be locked. The child & pets lock indicator will light on led display.
- Press and hold again the child lock button for 2 seconds and all functional buttons will be unlocked.


HOW TO REPLACE FILTER

FILTER REPLACE INDICATOR


- The smart replace filter indicator  illuminates when it is time to replace the True HEPA filter based on the air purifier's hours of use.
- For optimal performance, replace every 2,500 hours under normal usage conditions.
- Once the filter has been replaced, press and hold the filter replace filter button  for 5 seconds to reset the indicator. If reset successfully, the filter replace indicator will turn off.

HOW TO REPLACE FILTER


NOTE: for safety consideration, please do unplug the power adapter before starting to replace filter.




1. Gently snap the panel at the gap to ensure that the cover can be unlock.



2. Take the washable filters and old filters out.




3. Remove the new filter protective bag before installation.




4. Place the HEPA filters and washable filters into the air purifier, then install the side cover properly.

HOW TO USE THE AROMA BOX


1. Open the aroma box cover




2. Check the aroma cotton pad inside



3. Add essential oil on the pad



4. Close box cover and run the air purifier



Essential Oils

- **Add Essential Oils Only to the Aroma Pad:** Place essential oils only on the aroma pad located in the aroma box near the top of the air purifier.
- **Do Not Add Oils to the Air Purifier or Filter:** Avoid adding essential oils directly to any part of the air purifier or the filter. Doing so can damage the filter, leading to potential performance issues and an unpleasant odor.

Important Note: Essential oils are not included with the device.

CARE & MAINTENANCE

NOTE: For the best performance, please regularly to clean the washable pre-filter 2-4 week and vacuum the HEPA pre-filter once a month under normal usage.

Cleaning the Air Purifier

- Wipe the outside of the air purifier with a dry cloth. Do not clean with water or any other liquid to avoid risk of electric shock.
- the Washable Pre-Filter should be cleaned every 2-4 weeks to increase efficiency and extend the life of your filter. Clean the washable pre-filter using a soft brush or vacuum hose to remove hair, dust, and large particles. Optionally, you can wash the pre-filter with water and a mild detergent to remove dirt and dust.
- Clean the white side of the HEPA filter with a brush or vacuum hose each month to prevent buildup of hair or dust. **Do not clean the HEPA filter with water or other liquids.**

Storage

If not using the air purifier for an extended period of time, wrap the filter in plastic packaging and store in a dry place to avoid moisture damage.

When Should I Replace the Filter?

- The filter should be replaced every 3-4 months (2500h). But you may need to replace your filter earlier or later depending on how often you use your air purifier. Using your air purifier in an environment with relatively high pollution may mean you will need to change the filter more often, even if the filter replace indicator not illuminates yet.
- You may need to replace your filter if you notice the below situation:
 - Increased noise when the air purifier is on

- . Decreased airflow
- . Unusual odors
- . A visibly clogged filter

Maintaining Optimal Performance:

- **Use Official Filters:** To ensure the best performance and longevity of your air purifier, we recommend using only official filters.
- **Benefits:** Official filters are designed specifically for your device, ensuring maximum efficiency and effectiveness in air purification.

Cleaning Instructions for the Aroma

- **1. Remove the Aroma Box:** Open the aroma box located near the top of the air purifier and carefully remove it.
- **2. Clean the Aroma Pad:** Take out the aroma pad and gently wash it under warm running water. Do not use any liquid cleaners or detergents, as these can damage the pad and affect its performance.
- **3. Dry and Replace the Aroma Pad:** After washing, dry the aroma pad thoroughly with a clean cloth. Once dry, place it back into the aroma box.
- **4. Reinstall the Aroma Box:** Place the aroma box back into its designated location in the air purifier.

Important Note: Avoid using any liquid cleaners or detergents on the aroma pad or inside the aroma box to prevent damage and ensure optimal performance.

Guidelines for Replacing the Aroma Pad

- **1. Replace if Deformed or Damaged:** If the aroma pad becomes deformed, damaged, or shows signs of wear after multiple washes, it should be replaced to maintain effectiveness.
- **2. Change Pads Regularly with Fragrance Oil Refills:** If you are refilling the same fragrance oil onto the pad, it is advisable to change the pad every 90 to 120 days. Over time, the pad may lose its ability to effectively diffuse the fragrance.

- **3. Use Compatible, Non-Flammable Aroma Pads Only:** To ensure safe and effective operation, we recommend using heat-resistant, non-flammable pads designed for essential oils. Avoid materials that may degrade or release harmful substances over time.

Use Environment

Moisture may damage the filter. This air purifier should be used in an area with a humidity level below 85% RH. If you use the air purifier in excessively humid areas, the surface of the filter will become moldy.

Note: Water or moisture will allow mold to grow. Air purifiers cannot solve an existing mold problem, only reduce odors.

Warning:

- Do not wash or spill this product with liquid.
- Keep your hands and fingers away from the high-speed wheel component rotating in the purifier. Avoid foreign objects entering the unit air vent, it may cause heat or damage to the unit.
- Children shall not play with the air purifier. This appliance can be used by children.
- In order to improve the purification effect, close the doors and windows when using the unit (to avoid carbon monoxide poisoning, properly ventilate when using a combustion unit).
- Please do not use any other power adapter than the one provided with the air purifier.
- Do not use the appliance in wet, moist areas such as bathrooms, steamy kitchens, or near swimming pools, otherwise, it may cause an electric shock.

Note: Water or moisture will allow mold to grow. Air purifiers cannot solve an existing mold problem, only reduce odors.

Disposal and Recycling

This air purifier should be recycled as electronic waste and the filter recycled as plastic.

Tips to Buy Air Purifier

Clean Air Delivery Rate (CADR)

Clean Air Delivery Rate (CADR) measures the efficiency of an air purifier by indicating the volume of clean air that an air purifier produces per minute.

This is based on the removal of dust, dander, and smoke, which are the 3 most common indoor air pollutants.

The higher the CADR, the more particles the air purifier will remove and the larger the area it can clean. The rating is measured at the air purifier's highest speed.

But the CADR and the fan related to the noise, the higher CADR, the fan speed will be quicker, the noise will be louder too.

So please understand that if you use the higher fan speed and CADR air purifier, the noise will be a loud.

Air Change per Hour

The air change rate is how many times all of the air in a room can be purified (or "changed") by the air purifier in 1 hour. Air changes per hour are calculated on the recommended room size assuming 8ft /2.4m ceilings.

For smaller rooms, the air change per hour will increase.

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Contains FCCID:2ANDL-WBR3/Contains IC:23243-WBR3

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Air Purifier not operate	Unit is not plugged in	Plug the unit in
	Power button not pressed	Press the power button to turn the power on
	No power to unit	Check circuits, fuses, try a different outlet
Reduced airflow	The back grille may be blocked	Make sure side intakes are not blocked or the front outflow area
	Pre-filter needs vacuuming	Vacuum the pre-filter with the brush attachment of your vacuum cleaner
	The filter needs to be replaced	Replace the filter
Reduced odor removal	The filter needs to be replaced	Replace the filter
Excessive noise	The unit is not level	Place the unit on a flat and level surface
Replace filter light remains lit after filter replaced	The replace filter indicator needs to be reset	Press and hold the filter replace button for 5 seconds until the replace filter light turns off
Can't feel the effect	Filter failure-replace the filter .	Check if filter in correct location
	Use in inappropriate places (excessive area)	Use in bedroom, living room or other indoor places

If your problem is not listed here, please contact our Customer Support.